


...



...




FIGURE 1




FIGURE 2




FIGURE 3




FIGURE 4




FIGURE 5





FIGURE 6



87

FIGURE 7




FIGURE 8






FIGURE 9




FIGURE 10




FIGURE 11




FIGURE 12






FIGURE 14





FIGURE 15



16 APR 1964



1200




FIGURE 17




FIGURE 18

FIG. 19

FIBERS CONTINUE TO NEEDED DESTINATION  
SPRING PUSH LATCHES IN SLOT

140


SHUFFLE

ADAPTER GRIPS THE SHUFFLE

CLIP FIXES ADAPTER TO SPRING PUSH

OGI CARD CONNECTOR

FIGURE 19






FIGURE 20